

External temperature setpoint with room sensor RES 002/NTC



The RES 002/NTC is intended to be used for external temperature setpoint when it is connected to electric heater's controller REH .. installed in heaters EHC .. or EHR ..

Duct sensor with NTC element measures air temperature in ventilation ducts. Sensor with NTC element is for measuring air temperature in the room.

Model

Range	Article number
0...+30°C	RES 002/NTC

The other temperature range is available upon request.

Technical data

Protection class IP30

Potentiometer denomination 10 kΩ

Sensor element thermistor NTC10B25/85 (K)3977.

